
ELEIKO PRESTERA CABLE ATTACHMENT

Art.no. 3085601, 3085709, 3085850





CONTENTS

Read before installation and use	3
Safety instructions	3
Warning labels	4
Assembly instructions - General	5
Tools needed	5
Assembly instructions - Left side	6
List of components	7-10
Assembly instructions - Right side	35
List of components	36-39
User guide	64
Purpose	64
General instructions for use	64
Product specifications	64
Care and maintenance	65
Preventive maintenance and inspections	65
Spare parts and service	65
Warranty	65



READ BEFORE INSTALLATION AND USE

Install and use this equipment in a place where access and supervision are specifically controlled by the owner.

Be sure to install the equipment on a stable base and level the equipment properly. Eleiko recommends that all equipment is installed by a licensed contractor or an Eleiko installer.

This equipment is intended for indoor use only.

SAFETY INSTRUCTIONS


It is the responsibility of the purchaser of ELEIKO products to instruct all users and supervising personnel on proper usage of the equipment. It is also the responsibility of the purchaser of ELEIKO products to assess the suitability of the floor, and to choose appropriate fasteners depending on floor type when using ELEIKO products that needs to be bolted to the ground.

- 1. All included warnings (labels) and instructions MUST be read before the use of any Eleiko equipment. Only use the equipment as it is intended.
- 2. A user MUST get a medical examination and proper instructions before using any Eleiko equipment.
- 3. DO NOT let anyone, under any circumstances, use equipment that appears to be damaged. Do not try to repair any equipment before consulting an Eleiko technician.
- 4. DO NOT replace components of Eleiko equipment with other, none Eleiko, equipment (magnetic safety pin, frames, bars etc.). Do not improvise! If there are any doubts, consult an Eleiko representative prior to any intervention.
- 5. DO NOT overload the equipment and DO NOT try to exceed personal strength levels.
- 6. Children under the age of 14 must be supervised by an adult.
- 7. DO NOT remove any safety labels from the Eleiko equipment. Eleiko is not responsible if a label is removed. Replace damaged labels immediately.
- 8. Eleiko packaging for products an be made of wood. Be aware of splinters! You MUST use protective gloves and proper work wear.
- 9. Eleiko packaging material could be a risk when handling. Be aware of crushing! You MUST use work wear including protective gloves and hard shoes.
- 10. Eleiko products and packing material are heavy, You MUST use proper lifting techniques, work wear and hard shoes.

WARNING LABELS




Pinch point



When using Eleiko Prestera Cable Attachment for Eleiko Prestera Tall Rack, the rack MUST be bolted to the ground!


ASSEMBLY INSTRUCTIONS

Before assembly, make sure you have enough clearance on all sides of the equipment, not less than 0,6 meters. Take in account the accessibility to remove and replace bar and weights.




TOOLS NEEDED

You need the following tools to assemble the equipment.




NOTE: Do not use electric power tools for assembly.

ASSEMMBLY INSTRUCTIONS LEFT SIDE




ASSEMBLY INSTRUCTIONS FOR THE RIGHT SIDE CAN BE FOUND ON PAGE 35


Eleiko Prestera Cable Attachment Art.no 3085601 (120kg) & 3085850 (90kg)




Eleiko Prestera Cable Attachment Art.no 3085601 (120kg) & 3085850 (90kg)



Eleiko Prestera Cable Attachment - Tall Rack Art.no 3085709




Eleiko Prestera Cable Attachment - Tall Rack Art.no 3085709




PREPARATION


IF YOU HAVE ALSO PURCHASED A SVR INSERT PLATFORM, INSTALL THE PLATFORM FIRST!


BEFORE YOU START THIS ASSEMBLY, REMOVE EVENTUAL GLIDING J-CUPS AND/OR GLIDING SAFETY ARMS!






ALSO REMOVE THE RUBBER DAMPERS IF YOU HAVE ELEIKO PRESTERA STORAGE PINS, SAVE THESE FOR LATER!








When using Eleiko Prestera Cable Attachment for Eleiko Prestera Tall Rack, the rack MUST be bolted to the ground!





YOU WILL NOT NEED SCREWS AND COVER PLATE ANYMORE. SAVE THE PARTS IN CASE YOU REMOVE THE CABLE ATTACHMENT IN THE FUTURE!




























PLACE RODS IN TILTED POSITION IN THESE HOLES. RUBBER DAMPERS AND DISTANCE PLATES DOWN!


WIPE OFF BOTH RODS WITH A CLEAN CLOTH!








ASSEMBLE THE WEIGHT STACK PLATE BY PLATE! MAKE SURE THE FIRST PLATE IS PUSHED ALL THE WAY DOWN AND LOCKED IN POSITION!















MOUNT TOP WEIGHT AND PLASTIC TOP SUSPENSION! PUSH TO VERTICAL POSITION!








THE WEIGHT INCREMENT CAN NOW BE SECURED IN A TOP POSITION WITH HELP OF THE POP-PIN!











UNSCREW NUTS AND MOUNT BOTH WHEEL KITS!










3085601 a9


MOUNT THE TOP WHEEL ONE SCREW AT THE TIME! START WITH THE TOP ONE!










REMOVE PLATE AND REASSEMBLE ON UPRIGHT! BE CAREFUL NOT TO LET ANY PARTS FALL OUT!




MAKE SURE THE SCREWS ARE NOT TOO TIGHT! CARRIAGE SHOULD BE EASY TO ADJUST IN HEIGHT!













Hollow Screw



UNSCREW NUT AND MOUNT ON CARRIAGE!





SCREW SHOULD BE AS FAR DOWN AS POSSIBLE!
TENSION IN THE CABLE CAN LATER BE ADJUSTED BY MOVING THE SCREW UPWARDS!

18a.




Step 1 Step 2







Step 3









- 30 -




WIPE OFF BOTH RODS AGAIN WITH A CLEAN CLOTH BEFORE MOUNTING COVER PLATE!







2001483




SECURE SELECTOR PIN BY THREADING THE METAL RING INTO THE RIGHT HOLE!







THIS STEP ONLY APPLIES IF YOU HAVE STORAGE PINS!




FOR ELEIKO PRESTERA STORAGE PINS, FLIP EXISTING RUBBER DAMPERS AND USE THEM TOGETHER WITH FOUR NEW DAMPERS RECIEVED WITH ELEIKO PRESTERA CALBE ATTACHMENT! YOU WILL NOT NEED THE REMAINING FOUR DAMPERS!



FOR ELEIKO PRESTERA CHROMED STORAGE PINS, USE ALL EIGHT DAMPERS RECIEVED WITH ELEIKO PRESTERA CALBE ATTACHMENT!




ASSEMMBLY INSTRUCTIONS RIGHT SIDE




ASSEMBLY INSTRUCTIONS FOR THE LEFT SIDE CAN BE FOUND ON PAGE 6

Eleiko Prestera Cable Attachment Art.no 3085601 (120kg) & 3085850 (90kg)




LIST OF COMPONENTS

Eleiko Prestera Cable Attachment Art.no 3085601 (120kg) & 3085850 (90kg)




LIST OF COMPONENTS

Eleiko Prestera Cable Attachment - Tall Rack Art.no 3085709



LIST OF COMPONENTS


Eleiko Prestera Cable Attachment - Tall Rack Art.no 3085709




PREPARATION


IF YOU HAVE ALSO PURCHASED A SVR INSERT PLATFORM, INSTALL THE PLATFORM FIRST!


BEFORE YOU START THIS ASSEMBLY, REMOVE EVENTUAL GLIDING J-CUPS AND/OR GLIDING SAFETY ARMS!






ALSO REMOVE THE RUBBER DAMPERS IF YOU HAVE ELEIKO PRESTERA STORAGE PINS, SAVE THESE FOR LATER!








When using Eleiko Prestera Cable Attachment for Eleiko Prestera Tall Rack, the rack MUST be bolted to the ground!





YOU WILL NOT NEED SCREWS AND COVER PLATE ANYMORE. SAVE THE PARTS IN CASE YOU REMOVE THE CABLE ATTACHMENT IN THE FUTURE!






























PLACE RODS IN TILTED POSITION IN THESE HOLES. RUBBER DAMPERS AND DISTANCE PLATES DOWN!

WIPE OFF BOTH RODS WITH A CLEAN CLOTH!












ASSEMBLE THE WEIGHT STACK PLATE BY PLATE! MAKE SURE THE FIRST PLATE IS PUSHED ALL THE WAY DOWN AND LOCKED IN POSITION!












MOUNT TOP WEIGHT AND PLASTIC TOP SUSPENSION! PUSH TO VERTICAL POSITION!








THE WEIGHT INCREMENT CAN NOW BE SECURED IN A TOP POSITION WITH HELP OF THE POP-PIN!


13.







Single Wheel Kit





UNSCREW NUTS AND MOUNT BOTH WHEEL KITS!






1_X


14.




3085601 a9

MOUNT THE TOP WHEEL ONE SCREW AT THE TIME! START WITH THE TOP ONE!






15.





3085601 a3


REMOVE PLATE AND REASSEMBLE ON UPRIGHT! BE CAREFUL NOT TO LET ANY PARTS FALL OUT!




MAKE SURE THE SCREWS ARE NOT TOO TIGHT! CARRIAGE SHOULD BE EASY TO ADJUST IN HEIGHT!















UNSCREW NUT AND MOUNT ON CARRIAGE!




SCREW SHOULD BE AS FAR DOWN AS POSSIBLE!
TENSION IN THE CABLE CAN LATER BE ADJUSTED BY MOVING THE SCREW UPWARDS!


18a.



LET CABLE PASS INSIDE THIS SCREW!





Step 3




18b.








WIPE OFF BOTH RODS AGAIN WITH A CLEAN CLOTH BEFORE MOUNTING COVER PLATE!








2001483




SECURE SELECTOR PIN BY THREADING THE METAL RING INTO THE LEFT HOLE!









THIS STEP ONLY APPLIES IF YOU HAVE STORAGE PINS!



FOR ELEIKO PRESTERA STORAGE PINS, USE EXISTING RUBBER DAMPERS TOGETHER WITH FOUR NEW DAMPERS RECIEVED WITH ELEIKO PRESTERA CALBE ATTACHMENT! YOU WILL NOT NEED THE REMAINING FOUR DAMPERS!



FOR ELEIKO PRESTERA CHROMED STORAGE PINS, USE ALL EIGHT DAMPERS RECIEVED WITH ELEIKO PRESTERA CALBE ATTACHMENT!



USER GUIDE

PURPOSE

Cable attachment that enables a variety of exercises in a Eleiko Prestera Rack.

GENERAL INSTRUCTIONS FOR USE

- 1. Use the selector pin to select training weight.
- 2. Adjust height on carriage by pulling the pop-pin.
- 3. Switch to different handles depending on exercise.
- 4. Release 1,5 kg / 3,5 lbs weight increment by pulling pop-pin.
- 5. Adjust tension in cable with help of the hollow screw. See step 17 on page 28 and 57.

PRODUCT SPECIFICATION

Max training weight

3085850 90 kg / 198 lbs

3085601 & 3085709 120 kg / 265 lbs

Dimensions (L x W x H)

3085601 & 3085850 669 x 188 x 2331 mm / 26 x 7 x 92"


3085709 669 x 188 x 2581 mm / 26 x 7 x 102"


Product weight:


3085601 185 kg / 408 lbs


3085709 189 kg / 417 lbs

3085850 155 kg / 342 lbs









CARE AND MAINTENANCE

PREVENTIVE MAINTENANCE AND INSPECTIONS

NOTE: The safety level of the equipment can only be maintained if it is examined regularly for damage and wear.

Regularly:

- · Clean surfaces on the frames and tubes from dust and dirt.
- \cdot Check that all bolts between parts, walls and floors are properly tightened, according to recommendations.
- · Check equipment for sharp edges. Replace parts with sharp edges.

See also www.eleiko.com.

SPARE PARTS AND SERVICE

The following components are parts that are not listed in the list of components section. They may however need to be replaced eventually. The rest of the components can be found in the list of components section.



Contact Eleiko for spare parts and service:

Eleiko Group AB | Klastorpsvägen 18 | SE-302 62 HALMSTAD | Sweden E-mail: info@eleiko.com | Phone: +46 35 17 70 70 www.eleiko.com

WARRANTY

All products manufactured by ELEIKO are warranted to the original purchaser to be free from defects in workmanship and / or materials under normal use or service as follows:

- · 5 years on structural moving parts.
- \cdot 3 years on bearing, bushings and pulleys.
- · 1 year on cable and accessories.

ELEIKO