

### Notice!

The scale including instrument and platform is calibrated by Svenska Våg AB from delivery. Although you might need to do a new calibration on site depending on your location, due to the gravitational changes on earth.

Before the calibration make sure your scale is empty!

1. Press  to turn the instrument on/off
2. During the self test routine, while all display segments are counting down from 99999 to 11111 press 
3. When the display shows **Pn**. Press  follow by  and then  and **POCHt** will be presented on the display
4. Press  until the display shows **P3CAL**
5. Press  and the display shows **CoUnt**
6. Continue pressing  until the display shows **CAL**
7. Press  and the display shows **noL in**
8. Press  again and the display show **UnLd**. Make sure that the scale is empty. Wait until **STABLE** shows in the display
9. Press  and the display presents a value for example **100.00 kg**. Enter the correct calibration value, for example **050.00 kg** with  and 
10. When done entering the value press  and the display presents **LoAd**.  
Add your entered load on the scale in this case 50 kg. Wait until **STABLE** shows on the display, then press 
11. The display shows **PASS** and the instrument starts with the self test routine again as mentioned in step 2. You must unload the scale before the self test routine is finished otherwise the instrument shows **Err19**.  
If this should happen turn the instrument off by pressing   
Unload the scale and start the instrument again by pressing 
12. The calibration is now finished. If there are any problems during this process turn off the instrument and start from the beginning again.