
Eleiko Powerlifting Squat Stand/Bench Combo

Art.no. 3085245







READ BEFORE INSTALLATION AND USE

CAUTION

The equipment must be installed and used in a place whose access and supervision are specifically controlled by the owner.

Be sure to install the equipment on a stable base and properly level the equipment. ELEIKO recommends that all equipment is secured to floor and installed by a licensed contractor or an ELEIKO-installer.

SAFETY INSTRUCTIONS

It is the responibility of the purchaser of ELEIKO products to instruct all users and supervising personnel on proper usage of the equipment.

- 1. All included warnings (labels) and instructions **MUST** be read before the use of any ELEIKO-equipment. Use each equipment as it is intended for.
- 2. A user MUST get a medical examination and proper instructions before the use of any ELEIKO-equipment.
- **3. DO NOT** let anyone, under any cuircumstances, use equipment that appears to be damaged. Do not try to repair any equipment before consulting an ELEIKO technician.
- **4. DO NOT** replace the components of ELEIKO-equipment with other none ELEIKO-equipment (magnetic safety pin, frames, bars), do not improvise. If there are any doubts consult an ELEIKO representative prior to any intervention.
- 5. DO NOT overload the equipment and DO NOT try to exceed personal strength levels.
- 6. Children under the age of 14 must be supervised by an adult.
- **7. DO NOT** remove any safety labels from the ELEIKO-equipment. ELEIKO is not responsible if a label is removed. Replace damaged labels immediately.
- **8.** Eleiko package for products can be made of wood, be aware of splinters, MUST use gloves and proper work wear.
- **9.** Eleiko package material could be a risk when handling, be aware of crushing, MUST use work wear including gloves and hard shoes.
- 10. Eleiko products and packing material is heavy, MUST use proper lifting technique, work wear and hard shoes.

PREVENTITIVE MAINTENANCE & INSPECTIONS

DAILY:

Cleaning of upholstery.

REGULARLY:

Clean the surfaces on frames and tubes from dust and dirt.

Check that all bolts between parts, walls, floors are properly tightened, according to recommendations. Check euipment for sharp edges, replace parts with sharp edges.

WARRANTY

All products manufactured by ELEIKO are warranted to the original purchaser to be free from defects in workmanship and / or materials under normal use or service as follows:

10 years on welds on structural frame (NOT on moving parts)

1 year on upholstery

Normal wear and tear does not fall under the warranty of 10 years.

ADDITIONAL INFORMATION

This equipment is for indoor use only.




PRODUCT SPECIFICATIONS

Eleiko Powerlifting Squat Stand/Bench Combo is used for IPF powerlifting competitions and training. Bench press and squat are the two exercises it is made for.

To change height of uprights and safety arms, make sure no person is under or close to the bar, lift the upright or safety arm up and place the pin in correct hole, make sure to insert the pin properly. Lower the uprights or safety arms slowly until pin is in contact.

Product weight	115 kg 253 lbs
Max user weight	300 kg 661 lbs
Max training weight	750 kg 1650 lbs
Dimensions (L x W x H)	2010x1650x1875 mm 80" x 65" x 74"


FOOTPRINT AREA



Add sufficient clearance, not less than 0,6 m, on all sides. Taking in account the accessibility to remove and replace bar and weights




CONTENTS





REQUIRED TOOLS



Would **not** recommend electric power tools for assembly.

GENERAL


The table below is general torque to use for different threads. Use these torques, if nothing else is set. Below numbers are for screw/nut of quality 8.8.


THREAD	TORQUE (Nm / ftlb) Quality 8.8
M8	24 / 17,7
M10	47 / 34,7
M12	81 / 59,7




ASSEMBLY INSTRUCTIONS


1.



























Tighten the screws in order 1-8











x2




x6

Insert pin Magnetic 2001152




RXS 5,5x32 2000855-L32





6.



Tighten all screws properly
For safe use, be certain pins are properly inserted before load bar on bench.



6. Eleiko Powerlifting Squat Stand/Bench Combo is used for IPF powerlifting competitions and training. Bench press and squat are the two exercises it is intended for.

User Manual

Set up according to below:

