


Eleiko IPF Warm-up/training platform

Art.nr 3085118



ELEIKO

READ BEFORE INSTALLATION AND USE

CAUTION

The equipment must be installed and used in a place whose access and supervision are specifically controlled by the owner.

Be sure to install the equipment on a stable base and properly level the equipment. ELEIKO recommends that all equipment is secured to floor and installed by a licensed contractor or an ELEIKO-installer.

SAFETY INSTRUCTIONS

It is the responsibility of the purchaser of ELEIKO products to instruct all users and supervising personnel on proper usage of the equipment.

1. All included warnings (labels) and instructions **MUST** be read before the use of any ELEIKO-equipment. Use each equipment as it is intended for.
2. A user **MUST** get a medical examination and proper instructions before the use of any ELEIKO-equipment.
3. **DO NOT** let anyone, under any circumstances, use equipment that appears to be damaged. Do not try to repair any equipment before consulting an ELEIKO technician.
4. **DO NOT** replace the components of ELEIKO-equipment with other none ELEIKO-equipment (magnetic safety pin, frames, bars), do not improvise. If there are any doubts consult an ELEIKO representative prior to any intervention.
5. **DO NOT** overload the equipment and **DO NOT** try to exceed personal strength levels.
6. Children under the age of 14 must be supervised by an adult.
7. **DO NOT** remove any safety labels from the ELEIKO-equipment. ELEIKO is not responsible if a label is removed. Replace damaged labels immediately.

PREVENTITIVE MAINTENANCE & INSPECTIONS

DAILY:

Clean the textile carpet with a proper vacuum cleaner during the day, if needed use a cleaning machine like "clean profi 50.1" (HAKO) (including water, soap and brush).

REGULARLY:

Clean the surfaces on frames and tubes from dust and dirt.

Check that all bolts between parts, walls, floors are properly tightened, according to recommendations.

WARRANTY

All products manufactured by ELEIKO are warranted to the original purchaser to be free from defects in workmanship and / or materials under normal use or service as follows: 2 Years (Indoor use only)

Normal wear and tear does not fall under the warranty of two years.

USAGE DURING COMPETITION

Platform AND wrapping area should be cleaned in the breaks between every discipline. There is plenty of time for loaders to do this.

Platform, Wrapping area AND warm-up area must be cleaned between competition days.

Failure to keep these areas clean will result magnesias and Baby powder unavoidably getting on the soles of other lifters shoes, limiting their grip and thereby hindering their best performance. This is because magnesias and Baby powder is used so liberally during the competition and entire areas are quickly covered if not kept clean.

How to clean:

During the day a well-functioning vacuum cleaner is sufficient.

For the cleaning between days it is recommended to wet-wipe the floor and vacuum clean.


ELEIKO

PRODUCT SPECIFICATIONS

Powerlifting competition platform, indoor use only.

Product weight	230
Max user weight	200
Max training weight	600
Dimensions (L x W x H)	3174x2699x30 mm


FOOTPRINT AREA



Add sufficient clearance, not less than 0,6 m, on all sides.


CONTENTS

x1




Plywood 984x2520x21
2000336

x10




Rubber tile 1008x504x21
3085158

x1




Carpet 2530x3010
2001891

x1




Tape double sided
3001973

x4




Corner for platform 30 mm
3085217

x2




Profile tube 30x60x3 L=2502,5
2000521 p4

x2




Profile tube 30x60x3 L=2977,5
3085217

x8




Flat iron 20x6 L=120
2000520 p5

x16



Screw M10x25
2001124-L25

REQUIRED TOOLS



Torx key X50

GENERAL

The table below is general torque to use for different threads. Use these torques, if nothing else is set. Below numbers are for screw/nut of quality 8.8.

THREAD	TORQUE (Nm / ftlb) Quality 8.8
M10	47 / 34,7


ASSEMBLY INSTRUCTIONS

x4

x16

x8


1.





Corner for platform 30 mm
3085217



Screw M10x25
2001124-L25



Flat iron 20x6 L=120
Art: 2000520p5




Loose screws

ELEIKO


2.

x1





Plywood 984x2520x21
Art: 3085157

x10



Rubber tile 1008x504x21
Art: 2000336




x1

3.




Tape double sided
Art: 3001973




ELEIKO

x1

4.




Carpet 2530x3010
Art: 2001891



ELEIKO


5.

x4




Corner for platform 30 mm
3085217

x2





Profile tube 30x60x3 L=2502,5
Art: 2000251p3

x2



Profile tube 30x60x3 L=2977.5
Art: 2000251p4



ELEIKO



Eleiko Group AB | Klastorpsvägen 18 | SE-302 62 HALMSTAD | Sweden
E-mail: info@eleiko.com | Phone: +46 35 17 70 70

www.eleiko.com